

Devices with Connections

Director: R. Borski

Design: R. B. Ingraham

AMPLIFIERS

Name:	Make:	Model:	Description:	Location:	Patch:
Amp 01	GENERIC	Amp 2 Channel		Backstage	Stage Monitors
Connection:		Name:	Note:	Patch:	
In 01		Stage Monitor 01		Stage Snake BR01-Stage Monitor 01 (Cain Park Alma Stage Snake 01)	
In 02		Stage Monitor 02		Stage Snake BR02-Stage Monitor 02 (Cain Park Alma Stage Snake 01)	
Out 01		Stage Monitor 01		Stage Monitor 01:Wedge Monitor:	
Out 02		Stage Monitor 02		Stage Monitor 02:Wedge Monitor:	
Name:	Make:	Model:	Description:	Location:	Patch:
Amp 02	GENERIC	Amp 2 Channel		Backstage	Sub Amp
Connection:		Name:	Note:	Patch:	
In 01		Subwoofer		Stage Snake B28-Subwoofer (Cain Park Alma Stage Snake 01)	
In 02					
Out 01		Subwoofer		Subwoofer:SUB:	
Out 02					
Name:	Make:	Model:	Description:	Location:	Patch:
Amp 03	GENERIC	Amp 2 Channel		Backstage	Orchestra Monitors
Connection:		Name:	Note:	Patch:	
In 01		Orchestra Monitor Mix 01		Stage Snake BR03-Orchestra Monitor Mix 01 (Cain Park Alma Stage Snake 01)	
In 02		Orchestra Monitor Mix 02		Stage Snake BR04-Orchestra Monitor Mix 02 (Cain Park Alma Stage Snake 01)	
Out 01		Orchestra Monitor Mix 01		Orchestra Monitor 01 Input-Orchestra Monitor Mix 01 (Hot Spot VC)	
Out 02		Orchestra Monitor Mix 02		Orchestra Monitor 02 Input-Orchestra Monitor Mix 02 (Hot Spot VC)	
Name:	Make:	Model:	Description:	Location:	Patch:
Amp 04	GENERIC	Amp 2 Channel		Booth	Surround Amp
Connection:		Name:	Note:	Patch:	
In 01		Surround Left		Sound Card I/O 03 Output Main Left-Surround Left (1224)	
In 02		Surround Right		Sound Card I/O 03 Output Main Right-Surround Right (1224)	
Out 01A		Surround Left		Surround Left: SX80:	
Out 01B		Surround Left		Surround Left: SX80:	
Out 02A		Surround Right		Surround Right: SX80:	
Out 02B		Surround Right		Surround Right: SX80:	

CABLES and MULTICORE CABLES

Name:	Make:	Model:	Description:	Location:	Patch:
Return Snake	Generic	8 Channel Snake			Return Lines to Main Spakers
Connection:	Name:	Note:	Patch:		
A1	Main Center Speaker 01		Main Center Speaker 01 Input-Main Center Speaker 01 (KW153)		
A2	Main Center Speaker 02		Main Center Speaker 02 Input-Main Center Speaker 02 (KW153)		
A3	Main Center Speaker 03		Main Center Speaker 03 Input-Main Center Speaker 03 (KW153)		
A4	Main Left Speaker 01		Main Left Speaker 01 Input-Main Left Speaker 01 (K12)		
A5	Main Left Speaker 02		Main Left Speaker 02 Input-Main Left Speaker 02 (K12)		
A6	Main Right Speaker 01		Main Right Speaker 01 Input-Main Right Speaker 01 (K12)		
A7	Main Right Speaker 02		Main Right Speaker 02 Input-Main Right Speaker 02 (K12)		
A8					
B1	Main Center Speaker 01		Sound Card I/O 03 Output 01-Main Center Speaker 01 (1224)		
B2	Main Center Speaker 02		Sound Card I/O 03 Output 02-Main Center Speaker 02 (1224)		
B3	Main Center Speaker 03		Sound Card I/O 03 Output 03-Main Center Speaker 03 (1224)		
B4	Main Left Speaker 01		Sound Card I/O 03 Output 05-Main Left Speaker 01 (1224)		
B5	Main Left Speaker 02		Sound Card I/O 03 Output 06-Main Left Speaker 02 (1224)		
B6	Main Right Speaker 01		Sound Card I/O 03 Output 07-Main Right Speaker 01 (1224)		
B7	Main Right Speaker 02		Sound Card I/O 03 Output 08-Main Right Speaker 02 (1224)		
B8					
Name:	Make:	Model:	Description:	Location:	Patch:
Stage Snake	Venue Specific	Cain Park Alma Stage Snake 01		Backstage	
Connection:	Name:	Note:	Patch:		
B01	key 1 DI Left		key 1 DI Left Out-key 1 DI Left (TYPE 85)		
B02	key 1 DI Right		key 1 DI Right Out-key 1 DI Right (TYPE 85)		
B03	key 2 DI Left		key 2 DI Left Out-key 2 DI Left (TYPE 85)		
B04	key 2 DI Right		key 2 DI Right Out-key 2 DI Right (TYPE 85)		
B05	Guitar Acoustic Mic		Guitar Acoustic Mic:C 535 EB:		
B06	Guitar Amp Mic		Guitar Amp Mic:SM57:		
B07	Reed Mic		Reed Mic:C 535 EB:		
B08					
B09	Bass Mic		Bass Mic:C 414 B-TL II:		
B10	Bass DI		Bass DI Out-Bass DI (TYPE 85)		

CABLES and MULTICORE CABLES

Connection:	Name:	Note:	Patch:
B11	Drum OH 1		Drum OH 1:SM81:
B12	Drum OH 2		Drum OH 2:SM81:
B13	Drum Floor Tom		Drum Floor Tom:SM57:
B14	Drum Kick		Drum Kick:D112:
B15	Drum Bongo		Drum Bongo:SM57:
B16	Drum Trees		Drum Trees:SM57:
B17			
B18			
B19			
B20			
B21			
B22			
B23			
B24			
B25			
B26			
B27	A2 Headphone Mix		A2 Headphone Mix Input-A2 Headphone Mix (S-amp)
B28	Subwoofer		Amp 02 In 01-Subwoofer (Amp 2 Channel)
BR01	Stage Monitor 01		Amp 01 In 01-Stage Monitor 01 (Amp 2 Channel)
BR02	Stage Monitor 02		Amp 01 In 02-Stage Monitor 02 (Amp 2 Channel)
BR03	Orchestra Monitor Mix 01		Amp 03 In 01-Orchestra Monitor Mix 01 (Amp 2 Channel)
BR04	Orchestra Monitor Mix 02		Amp 03 In 02-Orchestra Monitor Mix 02 (Amp 2 Channel)
F01	key 1 DI Left		A to D #1 Mic In 01-key 1 DI Left (D8)
F02	key 1 DI Right		A to D #1 Mic In 02-key 1 DI Right (D8)
F03	key 2 DI Left		A to D #1 Mic In 03-key 2 DI Left (D8)
F04	key 2 DI Right		A to D #1 Mic In 04-key 2 DI Right (D8)
F05	Guitar Acoustic Mic		A to D #1 Mic In 05-Guitar Acoustic Mic (D8)
F06	Guitar Amp Mic		A to D #1 Mic In 06-Guitar Amp Mic (D8)
F07	Reed Mic		A to D #1 Mic In 07-Reed Mic (D8)
F08	MD God Mic		A to D #1 Mic In 08-MD God Mic (D8)
F09	Bass Mic		A to D #2 Mic In 01-Bass Mic (D8)
F10	Bass DI		A to D #2 Mic In 02-Bass DI (D8)
F11	Drum OH 1		A to D #2 Mic In 03-Drum OH 1 (D8)

CABLES and MULTICORE CABLES

Connection:	Name:	Note:	Patch:
F12	Drum OH 2		A to D #2 Mic In 04-Drum OH 2 (D8)
F13	Drum Floor Tom		A to D #2 Mic In 05-Drum Floor Tom (D8)
F14	Drum Kick		A to D #2 Mic In 07-Drum Kick (D8)
F15	Drum Bongo		
F16	Drum Trees		A to D #2 Mic In 08-Drum Trees (D8)
F17			
F18			
F19			
F20			
F21			
F22			
F23			
F24			
F25			
F26			
F27	A2 Headphone Mix		Sound Card I/O 01 Output 08-A2 Headphone Mix (2408 MKIII)
F28	Subwoofer		Sound Card I/O 03 Output 04-Subwoofer (1224)
FR01	Stage Monitor 01		Sound Card I/O 01 Output 03-Stage Monitor 01 (2408 MKIII)
FR02	Stage Monitor 02		Sound Card I/O 01 Output 04-Stage Monitor 02 (2408 MKIII)
FR03	Orchestra Monitor Mix 01		Sound Card I/O 01 Output 05-Orchestra Monitor Mix 01 (2408 MKIII)
FR04	Orchestra Monitor Mix 02		Sound Card I/O 01 Output 06-Orchestra Monitor Mix 02 (2408 MKIII)

COMPUTERS

Name:	Make:	Model:	Description:	Location:	Patch:
SAC	RML Labs	Software Audio Console		FOH	
Name:	Make:	Model:	Description:	Location:	Patch:
SAC Computer	Lenovo	Lenovo Tower		FOH	
Connection:	Name:	Note:	Patch:		
USB 01	Control Surface 01		Control Surface 01 USB-Control Surface 01 (BCF2000)		
USB 02	Control Surface 02		Control Surface 02 USB-Control Surface 02 (BCF2000)		
PCI Slot 01	Sound Card		Sound Card:424:		
Name:	Make:	Model:	Description:	Location:	Patch:
Sound Card	MOTU	424		FOH	SAC Computer PCI Slot 01-Sound Card (Lenovo Tower)
Connection:	Name:	Note:	Patch:		
Audiowire 01			Sound Card I/O 01 Audiowire-(2408 MKIII)		
Audiowire 02			Sound Card I/O 02 Audiowire-(2408 MKIII)		
Audiowire 03	System Outputs		Sound Card I/O 03 Audiowire-System Outputs (1224)		
Audiowire 04					
Name:	Make:	Model:	Description:	Location:	Patch:
Sound Card I/O 01	MOTU	2408 MKIII		FOH	
Connection:	Name:	Note:	Patch:		
Input 01	Wireless 01		Wireless 01:ULX Series Wirelss Lav Mic:		
Input 02	Wireless 02		Wireless 02:ULX Series Wirelss Lav Mic:		
Input 03	Wireless 03		Wireless 03:ULX Series Wirelss Lav Mic:		
Input 04	Wireless 04		Wireless 04:ULX Series Wirelss Lav Mic:		
Input 05	Wireless 05		Wireless 05:ULX Series Wirelss Lav Mic:		
Input 06	Wireless 06		Wireless 06:ULX Series Wirelss Lav Mic:		
Input 07	Wireless 07		Wireless 07:ULX Series Wirelss Lav Mic:		
Input 08	Wireless 08		Wireless 08:ULX Series Wirelss Lav Mic:		
Output 01					
Output 02					
Output 03	Stage Monitor 01		Stage Snake FR01-Stage Monitor 01 (Cain Park Alma Stage Snake 01)		
Output 04	Stage Monitor 02		Stage Snake FR02-Stage Monitor 02 (Cain Park Alma Stage Snake 01)		
Output 05	Orchestra Monitor Mix 01		Stage Snake FR03-Orchestra Monitor Mix 01 (Cain Park Alma Stage Snake 01)		

COMPUTERS

Connection:	Name:	Note:	Patch:
Output 06	Orchestra Monitor Mix 02		Stage Snake FR04-Orchestra Monitor Mix 02 (Cain Park Alma Stage Snake 01)
Output 07	Hearing Impaired		
Output 08	A2 Headphone Mix		Stage Snake F27-A2 Headphone Mix (Cain Park Alma Stage Snake 01)
Output Main Left			
Output Main Right			
Headpone Out	A1 Headphones		A1 Headphones Input-A1 Headphones (S-amp)
ADAT In A			
ADAT In B	Orchestra Mics 1-8		A to D #1 ADAT Out-Orchestra Mics 1-8 (D8)
ADAT In C	Orchestra Mics 9-16		A to D #2 ADAT Out-Orchestra Mics 9-16 (D8)
ADAT Out A			
ADAT Out B			
ADAT Out C			
Audiowire			Sound Card Audiowire 01- (424)
Wordclock In			Wordclock Out 4- (SyncGen)
Wordclock Out			

Name:	Make:	Model:	Description:	Location:	Patch:
Sound Card I/O 02	MOTU	2408 MKIII		FOH	

Connection:	Name:	Note:	Patch:
Input 01	Wireless 09		Wireless 09:ULX Series Wirelss Lav Mic:
Input 02	Wireless 10		Wireless 10:ULX Series Wirelss Lav Mic:
Input 03	Wireless 11		Wireless 11:ULX Series Wirelss Lav Mic:
Input 04	Wireless 12		Wireless 12:ULX Series Wirelss Lav Mic:
Input 05			
Input 06			
Input 07			
Input 08			
Output 01			
Output 02			
Output 03			
Output 04			
Output 05			
Output 06			
Output 07			
Output 08			

COMPUTERS

Connection:	Name:	Note:	Patch:
Output Main Left			
Output Main Right			
Headpone Out			
ADAT In A			
ADAT In B	Additional Mics		A to D #3 ADAT Out-Additional Mics (D8)
ADAT In C			
ADAT Out A			
ADAT Out B			
ADAT Out C			
Audiowire			Sound Card Audiowire 02- (424)
Wordclock In			
Wordclock Out			

Name:	Make:	Model:	Description:	Location:	Patch:
Sound Card I/O 03	MOTU	1224		FOH	

Connection:	Name:	Note:	Patch:
Input 01			
Input 02			
Input 03			
Input 04			
Input 05			
Input 06			
Input 07			
Input 08			
Output 01	Main Center Speaker 01		Return Snake B1-Main Center Speaker 01 (8 Channel Snake)
Output 02	Main Center Speaker 02		Return Snake B2-Main Center Speaker 02 (8 Channel Snake)
Output 03	Main Center Speaker 03		Return Snake B3-Main Center Speaker 03 (8 Channel Snake)
Output 04	Subwoofer		Stage Snake F28-Subwoofer (Cain Park Alma Stage Snake 01)
Output 05	Main Left Speaker 01		Return Snake B4-Main Left Speaker 01 (8 Channel Snake)
Output 06	Main Left Speaker 02		Return Snake B5-Main Left Speaker 02 (8 Channel Snake)
Output 07	Main Right Speaker 01		Return Snake B6-Main Right Speaker 01 (8 Channel Snake)
Output 08	Main Right Speaker 02		Return Snake B7-Main Right Speaker 02 (8 Channel Snake)
Output Main Left	Surround Left		Amp 04 In 01-Surround Left (Amp 2 Channel)
Output Main Right	Surround Right		Amp 04 In 02-Surround Right (Amp 2 Channel)
AES/EBU In			

COMPUTERS

Connection:	Name:	Note:	Patch:
AES/EBU Out			
Audiowire	System Outputs		Sound Card Audiowire 03-System Outputs (424)
Wordclock In			
Wordclock Out			

MICROPHONE ACCESSORIES

Name:	Make:	Model:	Description:	Location:	Patch:
Bass Mic	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Bongo	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Floor Tom	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Kick	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum OH 1	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum OH 2	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Trees	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Guitar Acoustic Mic	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Guitar Amp Mic	Generic	Mic Stand Boom			
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 01	Generic	Mic Stand Straight			
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 02	Generic	Mic Stand Straight			
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 03	Generic	Mic Stand Straight			
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 04	Generic	Mic Stand Straight			
Name:	Make:	Model:	Description:	Location:	Patch:
Reed Mic	Generic	Mic Stand Boom			

MICROPHONES

Name:	Make:	Model:	Description:	Location:	Patch:
Bass DI	COUNTRYMAN	TYPE 85			
	Connection:	Name:	Note:	Patch:	
	In				
	Thru				
	Out	Bass DI		Stage Snake B10-Bass DI (Cain Park Alma Stage Snake 01)	
Name:	Make:	Model:	Description:	Location:	Patch:
Bass Mic	AKG	C 414 B-TL II			Stage Snake B09-Bass Mic (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Bongo	SHURE	SM57			Stage Snake B15-Drum Bongo (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Floor Tom	SHURE	SM57			Stage Snake B13-Drum Floor Tom (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Kick	AKG	D112			Stage Snake B14-Drum Kick (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum OH 1	SHURE	SM81			Stage Snake B11-Drum OH 1 (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum OH 2	SHURE	SM81			Stage Snake B12-Drum OH 2 (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Drum Trees	SHURE	SM57			Stage Snake B16-Drum Trees (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Guitar Acoustic Mic	AKG	C 535 EB			Stage Snake B05-Guitar Acoustic Mic (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
Guitar Amp Mic	SHURE	SM57			Stage Snake B06-Guitar Amp Mic (Cain Park Alma Stage Snake 01)
Name:	Make:	Model:	Description:	Location:	Patch:
key 1 DI Left	COUNTRYMAN	TYPE 85			
	Connection:	Name:	Note:	Patch:	
	In				
	Thru				
	Out	key 1 DI Left		Stage Snake B01-key 1 DI Left (Cain Park Alma Stage Snake 01)	
Name:	Make:	Model:	Description:	Location:	Patch:
key 1 DI Right	COUNTRYMAN	TYPE 85			

MICROPHONES

Connection:	Name:	Note:	Patch:		
In					
Thru					
Out	key 1 DI Right		Stage Snake B02-key 1 DI Right (Cain Park Alma Stage Snake 01)		
Name:	Make:	Model:	Description:	Location:	Patch:
key 2 DI Left	COUNTRYMAN	TYPE 85			
Connection:	Name:	Note:	Patch:		
In					
Thru					
Out	key 2 DI Left		Stage Snake B03-key 2 DI Left (Cain Park Alma Stage Snake 01)		
Name:	Make:	Model:	Description:	Location:	Patch:
key 2 DI Right	COUNTRYMAN	TYPE 85			
Connection:	Name:	Note:	Patch:		
In					
Thru					
Out	key 2 DI Right		Stage Snake B04-key 2 DI Right (Cain Park Alma Stage Snake 01)		
Name:	Make:	Model:	Description:	Location:	Patch:
Reed Mic	AKG	C 535 EB			Stage Snake B07-Reed Mic (Cain Park Alma Stage Snake 01)

MISCELLANEOUS

Name:	Make:	Model:	Description:	Location:	Patch:
A1 Headphones	SAMSON	S-amp		FOH	
Connection:		Name:	Note:	Patch:	
Input	A1 Headphones			Sound Card I/O 01 Headpone Out-A1 Headphones (2408 MKIII)	
Out 1					
Out 2					
Out 3					
Out 4					
Name:	Make:	Model:	Description:	Location:	Patch:
A2 Headphone Mix	SAMSON	S-amp		Backstage	
Connection:		Name:	Note:	Patch:	
Input	A2 Headphone Mix			Stage Snake B27-A2 Headphone Mix (Cain Park Alma Stage Snake 01)	
Out 1					
Out 2					
Out 3					
Out 4					
Name:	Make:	Model:	Description:	Location:	Patch:
Control Surface 01	Behringer	BCF2000		FOH	
Connection:		Name:	Note:	Patch:	
USB	Control Surface 01			SAC Computer USB 01-Control Surface 01 (Lenovo Tower)	
MIDI In				GO Button MIDI Out A- (CM8)	
MIDI Out A					
MIDI Out B					
Footswitch					
Foot Controller					
Name:	Make:	Model:	Description:	Location:	Patch:
Control Surface 02	Behringer	BCF2000		FOH	
Connection:		Name:	Note:	Patch:	
USB	Control Surface 02			SAC Computer USB 02-Control Surface 02 (Lenovo Tower)	
MIDI In					
MIDI Out A					
MIDI Out B					
Footswitch					
Foot Controller					
Name:	Make:	Model:	Description:	Location:	Patch:
GO Button	Cue One	CM8		FOH	
Connection:		Name:	Note:	Patch:	
MIDI In A					

MISCELLANEOUS

Connection:	Name:	Note:	Patch:
MIDI In B			
MIDI Out A			Control Surface 01 MIDI In- (BCF2000)
MIDI Out B			

Name:	Make:	Model:	Description:	Location:	Patch:
Wordclock	ART	SyncGen		FOH	

Connection:	Name:	Note:	Patch:
Out 1			A to D #1 Wordclock In- (D8)
Out 2			A to D #2 Wordclock In- (D8)
Out 3			A to D #3 Wordclock In- (D8)
Out 4			Sound Card I/O 01 Wordclock In- (2408 MKIII)
SPDIF Out 1			
SPDIF Out 2			

PROCESSING

Name:	Make:	Model:	Description:	Location:	Patch:
A to D #1	Presonus	D8		FOH	
Connection:	Name:	Note:	Patch:		
Mic In 01	key 1 DI Left		Stage Snake F01-key 1 DI Left (Cain Park Alma Stage Snake 01)		
Mic In 02	key 1 DI Right		Stage Snake F02-key 1 DI Right (Cain Park Alma Stage Snake 01)		
Mic In 03	key 2 DI Left		Stage Snake F03-key 2 DI Left (Cain Park Alma Stage Snake 01)		
Mic In 04	key 2 DI Right		Stage Snake F04-key 2 DI Right (Cain Park Alma Stage Snake 01)		
Mic In 05	Guitar Acoustic Mic		Stage Snake F05-Guitar Acoustic Mic (Cain Park Alma Stage Snake 01)		
Mic In 06	Guitar Amp Mic		Stage Snake F06-Guitar Amp Mic (Cain Park Alma Stage Snake 01)		
Mic In 07	Reed Mic		Stage Snake F07-Reed Mic (Cain Park Alma Stage Snake 01)		
Mic In 08	MD God Mic		Stage Snake F08-MD God Mic (Cain Park Alma Stage Snake 01)		
ADAT Out	Orchestra Mics 1-8		Sound Card I/O 01 ADAT In B-Orchestra Mics 1-8 (2408 MKIII)		
Wordclock In			Wordclock Out 1- (SyncGen)		

Name:	Make:	Model:	Description:	Location:	Patch:
A to D #2	Presonus	D8		FOH	
Connection:	Name:	Note:	Patch:		
Mic In 01	Bass Mic		Stage Snake F09-Bass Mic (Cain Park Alma Stage Snake 01)		
Mic In 02	Bass DI		Stage Snake F10-Bass DI (Cain Park Alma Stage Snake 01)		
Mic In 03	Drum OH 1		Stage Snake F11-Drum OH 1 (Cain Park Alma Stage Snake 01)		
Mic In 04	Drum OH 2		Stage Snake F12-Drum OH 2 (Cain Park Alma Stage Snake 01)		
Mic In 05	Drum Floor Tom		Stage Snake F13-Drum Floor Tom (Cain Park Alma Stage Snake 01)		
Mic In 06	Drum Kick				
Mic In 07	Drum Kick		Stage Snake F14-Drum Kick (Cain Park Alma Stage Snake 01)		
Mic In 08	Drum Trees		Stage Snake F16-Drum Trees (Cain Park Alma Stage Snake 01)		
ADAT Out	Orchestra Mics 9-16		Sound Card I/O 01 ADAT In C-Orchestra Mics 9-16 (2408 MKIII)		
Wordclock In			Wordclock Out 2- (SyncGen)		

Name:	Make:	Model:	Description:	Location:	Patch:
A to D #3	Presonus	D8		FOH	
Connection:	Name:	Note:	Patch:		
Mic In 01					
Mic In 02					
Mic In 03					
Mic In 04					

PROCESSING

Connection:	Name:	Note:	Patch:
Mic In 05			
Mic In 06			
Mic In 07	SM God Mic		
Mic In 08	VOG Mic		
ADAT Out	Additional Mics		Sound Card I/O 02 ADAT In B- Additional Mics (2408 MKIII)
Wordclock In			Wordclock Out 3- (SyncGen)

SPEAKERS

Name:	Make:	Model:	Description:	Location:	Patch:
Main Center Speaker 01	QSC	KW153		Grid	House Left
Connection:		Name:		Note:	
Input	Main Center Speaker 01			Return Snake A1-Main Center Speaker 01 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Center Speaker 02	QSC	KW153		Grid	House Center
Connection:		Name:		Note:	
Input	Main Center Speaker 02			Return Snake A2-Main Center Speaker 02 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Center Speaker 03	QSC	KW153		Grid	House Right
Connection:		Name:		Note:	
Input	Main Center Speaker 03			Return Snake A3-Main Center Speaker 03 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Left Speaker 01	QSC	K12		Grid	Downstage Left
Connection:		Name:		Note:	
Input	Main Left Speaker 01			Return Snake A4-Main Left Speaker 01 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Left Speaker 02	QSC	K12		Grid	Upstage Left
Connection:		Name:		Note:	
Input	Main Left Speaker 02			Return Snake A5-Main Left Speaker 02 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Right Speaker 01	QSC	K12		Grid	Downstage Right
Connection:		Name:		Note:	
Input	Main Right Speaker 01			Return Snake A6-Main Right Speaker 01 (8 Channel Snake)	
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Main Right Speaker 02	QSC	K12		Grid	Upstage Right
Connection:		Name:		Note:	
Input	Main Right Speaker 02			Return Snake A7-Main Right Speaker 02 (8 Channel Snake)	
Thru					

SPEAKERS

Orchestra Monitor 01	GALAXY AUDIO	Hot Spot VC			MD Monitor
Connection:		Name:		Note:	
Input	Orchestra Monitor Mix 01				Amp 03 Out 01-Orchestra Monitor Mix 01 (Amp 2 Channel)
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 02	GALAXY AUDIO	Hot Spot VC			
Connection:		Name:		Note:	
Input	Orchestra Monitor Mix 02				Amp 03 Out 02-Orchestra Monitor Mix 02 (Amp 2 Channel)
Thru					Orchestra Monitor 03 Input- (Hot Spot VC)
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 03	GALAXY AUDIO	Hot Spot VC			
Connection:		Name:		Note:	
Input					Orchestra Monitor 02 Thru- (Hot Spot VC)
Thru					Orchestra Monitor 04 Input- (Hot Spot VC)
Name:	Make:	Model:	Description:	Location:	Patch:
Orchestra Monitor 04	GALAXY AUDIO	Hot Spot VC			
Connection:		Name:		Note:	
Input					Orchestra Monitor 03 Thru- (Hot Spot VC)
Thru					
Name:	Make:	Model:	Description:	Location:	Patch:
Stage Monitor 01		Wedge Monitor			Amp 01 Out 01-Stage Monitor 01 (Amp 2 Channel) - SR
Name:	Make:	Model:	Description:	Location:	Patch:
Stage Monitor 02		Wedge Monitor			Amp 01 Out 02-Stage Monitor 02 (Amp 2 Channel) - SL
Name:	Make:	Model:	Description:	Location:	Patch:
Stage Monitor 03		Wedge Monitor			Spare
Name:	Make:	Model:	Description:	Location:	Patch:
Stage Monitor 04		Wedge Monitor			Spare
Name:	Make:	Model:	Description:	Location:	Patch:
Subwoofer	ELECTRO-VOICE	SUB			Amp 02 Out 01-Subwoofer (Amp 2 Channel) - Upstage
Name:	Make:	Model:	Description:	Location:	Patch:
Surround Left	ELECTRO-VOICE	SX80			Amp 04 Out 01A-Surround Left (Amp 2 Channel) - Left - Rear Left
Name:	Make:	Model:	Description:	Location:	Patch:

SPEAKERS

Surround Left	ELECTRO-VOICE	SX80			Amp 04 Out 01B-Surround Left (Amp 2 Channel) - Left - Rear Right
Name:	Make:	Model:	Description:	Location:	Patch:
Surround Right	ELECTRO-VOICE	SX80			Amp 04 Out 02A-Surround Right (Amp 2 Channel) - Right - Rear Left
Name:	Make:	Model:	Description:	Location:	Patch:
Surround Right	ELECTRO-VOICE	SX80			Amp 04 Out 02B-Surround Right (Amp 2 Channel) - Right - Rear Right

WIRELESS MICROPHONES

Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 01	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 01-Wireless 01 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 02	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 02-Wireless 02 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 03	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 03-Wireless 03 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 04	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 04-Wireless 04 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 05	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 05-Wireless 05 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 06	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 06-Wireless 06 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 07	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 07-Wireless 07 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 08	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 01 Input 08-Wireless 08 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 09	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 02 Input 01-Wireless 09 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 10	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 02 Input 02-Wireless 10 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 11	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 02 Input 03-Wireless 11 (2408 MKIII)
Name:	Make:	Model:	Description:	Location:	Patch:
Wireless 12	SHURE	ULX Series Wirelss Lav Mic		FOH	Sound Card I/O 02 Input 04-Wireless 12 (2408 MKIII)